



Correct Answer:

B. Begin light hydraulic cycling at low idle

Why:

Gently cycling hydraulics at low idle warms oil evenly, improves flow, and reduces stress on pumps, valves, and seals. Jumping straight to high RPM or load risks damage—especially in extreme cold.