

 **Correct Answer:**

C — Track pins & bushings

 **Why:**

Over-tightened tracks can't absorb shock. In rock work, repeated impact loading and pivot turns force metal-to-metal contact, accelerating wear, heat buildup, and chain elongation—causing pins and bushings to fail well before major driveline or hydraulic components.